

UUALK SUN'14 - ASSEMBLING INSTRUCTIONS

1. You will receive a package like the one shown in the picture, of dimensions: 150 cm long, 78 cm high and 26 cm wide .
2. To assemble the bike Uualk Sun'14 the following tools are needed:
 - a) Scissors or cutter.
 - b) Allen wrench no. 4, 5 and 6
 - c) Monkey wrench or a flat one no. 15 .
 - d) Flat or star screwdriver.
3. Remove the packaging. Inside the box you will find:
 - a) Your bike already mounted with the battery and the rear wheel.
 - b) Two pedals.
 - c) Front fender.
 - d) Battery charger.
 - e) Front wheel and quick lamping axis.
 - f) Handlebar (two battery keys attached to it).
 - g) Throttle lever.
 - h) Assembling instructions.
4. Remove with the cutter all paper and plastic protectors.
5. Remove the battery using the key and put it to charge. Very important: First connect the cable to the battery and then the charger to the electricity. To disconnect, first disconnect the power cord and then the battery. **IT IS ESSENTIAL THAT THE FIRST LOAD LASTS FOR 12 HOURS.** Subsequent charges will be completed when the CHARGE indicator turns green (for 4-6 hours).
6. Remove the handlebar's plastic protector and place the handlebar in its axis. Screw it with the help of the allen wrench no. 6.
7. Loosen the brake to put the fender. Holding the front light, use the allen wrench no. 5 to unscrew the screw and place the fender's metal plate between the frame and the light. This is the best way to screw the hole combination all at once.
8. Tighten the spokes on the front wheel frame using the allen wrench no. 4



9. Place the front wheel. Wheel position is indifferent since it has no right-left differences. Place the shaft with quick release lever and adjust the wheel to set it properly.



10. Place the brake cable on the front wheel by removing the black rubber to the left and try to fit it with the bracket's thinnest part. Some strength and a little patience is needed. To facilitate this, loosen the tension cable with allen wrench no. 5, put every piece in place, re-tension the cable and tighten the screw once again. Ensure that the wheel rolls without being touched by the brake pads and the brake lever has an adequate roll.



11. Place the pedals taking into account they have **Right** and **Left** position. The pedal on the right is marked with the letter **R** and left with **L**. Screw them properly with wrench no. 15. Remember all pedals are screwed forward in order to prevent unscrewing during pedalling.



12. Once the battery is charged you can put it in place. Very important: Remember to keep a copy of the battery keys in a safe place and/or make a third copy. We have no extra replacement keys.

13. Put the saddle at a proper height for the rider. Tightly screw the mounting handle.

14. Inflate the wheels according to the pressure indicated on the tires

HIGHLY IMPORTANT:

It is better to keep the battery at a high level of charge. Do not wait for it to be completely discharged. Even if you do not use the bike for two months, we recommend to fully charge the battery at least once. Try not to expose the battery to extreme temperatures (below 10°C or above 40 °C).



¡Now it is time to enjoy your UuALK SUN'14!

Please, contact with Uualk team in case of any doubt.

info@uwalk.com

www.uwalk.com